




HOW TO CONNECT YOUR LEIKR WATCH TO THE WI-FI
AND
ACCESS YOUR LEIKR AND ENDOMONDO
ON-LINE ACCOUNTS



INSERT YOUR LEIKR WATCH IN THE CHARGER AND ATTACH THE
CHARGER TO THE COMPUTER



GO TO THE LEIKR CONFIGURATION MODULE AND PRESS "REGISTER"



The image shows the Leikr website's configuration module. The header features the Leikr logo on the left and navigation links 'The Team WE CREATE', 'Devices TO POWER YOU', and 'Configure YOUR DEVICE' on the right. A red banner at the top contains the text 'GO TO THE LEIKR CONFIGURATION MODULE AND PRESS "REGISTER"'. The left sidebar lists various settings categories: 'Device settings' (highlighted), 'Personal profile', 'Training targets', 'Workouts' (with sub-items 'Workout selection', 'Leikr workouts', and 'Workout editor'), 'Maps', and 'Account and connectivity'. The main content area is titled 'Device settings' and contains several configuration options: 'Time zone' (a dropdown menu showing 'Select Time Zone'), 'Units' (a dropdown menu showing 'Metric'), 'Auto lap' (a checkbox with a 'km' unit input field), 'Auto pause' (a checkbox), 'Sound level' (a dropdown menu showing 'Off'), 'Vibration' (a checkbox), 'Backlight duration' (a dropdown menu showing 'on/off'), and 'Message duration' (a dropdown menu showing '2 seconds'). A red box highlights the 'Register' button in the top right corner, with a red arrow pointing to it from a 'Preview coming soon' banner. An 'Update settings' button is located at the bottom right of the settings area.

Leikr

The Team
WE CREATE

Devices
TO POWER YOU

Configure
YOUR DEVICE

Log in Register

Preview coming soon

Device settings

Time zone ? Select Time Zone

Units Metric

Auto lap ? ☐ km

Auto pause ? ☐

Sound level Off


Vibration ? ☐

Backlight duration ? on/off

Message duration ? 2 seconds

Update settings

TYPE YOUR NAME, E-MAIL, PASSWORD



The image shows the Leikr website's registration page. The header features the Leikr logo on the left and navigation links 'The Team WE CREATE', 'Devices TO POWER YOU', and 'Configure YOUR DEVICE' on the right. A 'Log in Register' link is also present. The left sidebar contains a 'Device settings' menu with options like 'Personal profile', 'Training targets', 'Workouts', 'Workout selection', 'Leikr workouts', 'Workout editor', 'Maps', and 'Account and connectivity'. The main content area is titled 'Registration: Create account' and shows the progress 'Registration: Create account - Personal data - Complete'. The form includes fields for 'Name', 'E-mail', 'Password', and 'Confirm password', each with a red arrow pointing to it. There are also checkboxes for 'Open Wifi' and 'Password protected Wifi', and a section for adding or deleting Wifi networks. A red 'Create account' button is at the bottom right.

Leikr

The Team
WE CREATE

Devices
TO POWER YOU

Configure
YOUR DEVICE

[Log in](#) [Register](#)

Registration: [Create account](#) - Personal data - Complete

Registration: Create account

Name ?

E-mail ?

Password ?

Confirm password

Open Wifi ? ☐

Password protected Wifi ?

network name [Delete network](#)

[Add network](#)

[Create account](#)

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts


Workout editor

Maps

Account and connectivity

Your e-mail and password will be used as log in credential to access your Leikr account.

TYPE THE NAME OF YOUR WI-FI AND ITS PASSWORD



The image shows the Leikr website's registration page. The header features the Leikr logo on the left and navigation links 'The Team WE CREATE', 'Devices TO POWER YOU', and 'Configure YOUR DEVICE' on the right. A 'Log in Register' link is also present. The left sidebar contains a 'Device settings' menu with options like 'Personal profile', 'Training targets', 'Workouts', 'Workout selection', 'Leikr workouts', 'Workout editor', 'Maps', and 'Account and connectivity'. The main content area is titled 'Registration: Create account' and includes a progress bar showing 'Create account - Personal data - Complete'. The form fields are: 'Name' (placeholder: 'your name here'), 'E-mail' (placeholder: 'test@test.com'), 'Password' (placeholder: '*****'), and 'Confirm password' (placeholder: '*****'). Below these is a checkbox for 'Open Wifi'. The 'Password protected Wifi' section has a 'network name' input field and a 'Delete network' link. A red arrow points to the 'network name' field, and another red arrow points to the 'Delete network' link. A red button labeled 'Create account' is at the bottom right. A text box at the bottom left explains that the network name can be found on a computer in the list of available networks.

Leikr

The Team
WE CREATE

Devices
TO POWER YOU

Configure
YOUR DEVICE

Log in Register

Registration: [Create account](#) - Personal data - Complete

Registration: Create account

Name ? your name here

E-mail ? test@test.com

Password ? *****

Confirm password *****

Open Wifi ? ☐

Password protected Wifi ?


network name Delete network

Add network

Create account

The network name can be found on your computer in the list of available networks.

PRESS CREATE ACCOUNT



[The Team](#)
WE CREATE

[Devices](#)
TO POWER YOU

[Configure](#)
YOUR DEVICE

[Log in](#) [Register](#)

Device settings
Personal profile
Training targets
Workouts
 Workout selection
 Leikr workouts
 Workout editor
Maps
Account and connectivity

Registration: [Create account](#) - Personal data - Complete

Registration: Create account

Name ?

Your name here

E-mail ?

test@test.com

Password ?

Confirm password

Open Wifi ?

☐

Password protected Wifi ?

network name

Delete network

Add network

Create account

A COMMUNICATION BOX WILL APPEAR

Device settings

- Personal profile
- Training targets
- Workouts
 - Workout selection
 - Leikr workouts
 - Workout editor
- Maps
- Account and connectivity

Registration: Create account - **Wifi configuration** - Personal data - Complete

Hello your name here [Log out](#)

Register: Wifi configuration

Please follow the procedure below to enable wifi access on your watch:

1. Make sure that your Leikr watch is correctly inserted in the charger (Leikr logo down) and that the charger is connected to your computer's USB port (use the Leikr cable to connect the charger).
2. Find the Leikr drive on your computer. You can find it under 'Computer' along with the other drives.
3. Your browser is asking you if you would like to save the file 'leikr_config.cnf'. Please save this file on the Leikr drive.
4. On your Leikr watch: press the two visible buttons simultaneously to start the synchronization process. The watch will show its unique ID on the display.
5. Press the button 'Continue' below.

Notice: In case the watch does not show its unique ID but the message 'No Wifis configured on the watch.', please press the 'Back' button below to go back to the 'Create account' page and make sure you typed in the credentials for your Wifi.

[Back](#) [Continue](#)

To enable WiFi access follow the instruction written on the page.

Do you want to open or save **leikr_config.cnf** from **config.leikr.com**? [Open](#) [Save](#) [Cancel](#) [x](#)

CHOOSE THE OPTION "SAVE AS"

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

+ The Device settings

+ Time zone

+ Units

+ Autolap

+ Autopause

+ Sound level and vibration

+ Backlight duration

+ Message duration

Hello your name here [Log out](#)

Registration: Create account - **Wifi configuration** - Personal data - Complete

Register: Wifi configuration

Please follow the procedure below to enable wifi access on your watch:

1. Make sure that your Leikr watch is correctly inserted in the charger (Leikr logo down) and that the charger is connected to your computer's USB port (use the Leikr cable to connect the charger).
2. Find the Leikr drive on your computer. You can find it under 'Computer' along with the other drives.
3. Your browser is asking you if you would like to save the file 'leikr_config.cnf'. Please save this file on the Leikr drive.
4. On your Leikr watch: press the two visible buttons simultaneously to start the synchronization process. The watch will show its unique ID on the display.
5. Press the button 'Continue' below.

Notice: In case the watch does not show its unique ID but the message 'No Wifis configured on the watch.', please press the 'Back' button below to go back to the 'Create account' page and make sure you typed in the credentials for your Wifi.

Back

Continue

Do you want to open or save **leikr_config.cnf** from **config.leikr.com**?

Open

Save

Save

Save as

Save and open

SAVE THE "LEIKR_CONF.COM" FILE ON THE LEIKR DRIVE

The image shows a Windows 'Save As' dialog box in the foreground, overlaid on a web browser window. The dialog box is titled 'Save As' and shows the path 'Computer > Leikr (G:)' in the address bar, which is highlighted with a red rectangle. A red arrow points to the 'Leikr (G:)' folder in the left sidebar. The main pane shows 'No items match your search.' The 'File name' field contains 'leikr_config' and the 'Save as type' is set to 'CNF File'. A red arrow points to the 'Save' button, which is also highlighted with a red rectangle. The background web browser window shows the 'Device settings | Leikr' page. It includes a 'Hello your name here' greeting, a 'Log out' link, and a 'Wifi configuration' section. The 'Wifi configuration' section has a 'Complete' status and a 'Continue' button. Below this, there is a 'Back' button and a 'Continue' button. At the bottom of the browser window, a yellow bar contains the text 'Do you want to open or save leikr_config.cnf from config.leikr.com?' with 'Open', 'Save', and 'Cancel' buttons.

Save As

Computer > Leikr (G:)

Organize New folder

File name: leikr_config

Save as type: CNF File

Save Cancel

Device settings | Leikr

More >>

Hello your name here Log out

Wifi configuration - Personal data - Complete

Continue


Back Continue

Do you want to open or save leikr_config.cnf from config.leikr.com?

Open Save Cancel

The Leikr drive can be found, along with all the other Drives, under "computer".

PRESS THE TWO TOP KEYS ON THE LEIKR WATCH: THE 12 DIGITS
DEVICE ID WILL SHOW ON THE DEVICE SCREEN



COPY THE DEVICE ID TO THE CONFIGURATION MODULE AND CREATE A DEVICE NAME

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

Hello your name here [Log out](#)

Registration: Create account - **Personal data** - Complete

Registration: Personal data

Name ? cristiano cairo

Device name ? Your device name

Device ID ? 123456789012

Endomondo user id ?

Endomondo password ?

Date of birth ? 31 12 2013

Gender Female

Height 0 cm

Weight 70,0 kg

[Back](#) [Continue](#)

The 12 digits device ID are shown on the device screen.
The device name is of your choice.
Once you have copied the device ID please press "ok" on the device.

TYPE YOUR ENDOMONDO CREDENTIALS (OPTIONAL)

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

Registration: Create account - Personal data - Complete

Hello your name here [Log out](#)

Registration: Personal data

Name ? cristiano cairo

Device name ? Your device name

Device ID ? 123456789012

Endomondo user id ? Endo@test.com

Endomondo password ? *****

Date of birth ? 31 12 2013

Gender Female

Height 0 cm

Weight 70,0 kg

Back

Continue

The Endomondo user ID and password are the ones you use to access your Endomondo page.

TYPE YOUR PERSONAL INFORMATION (OPTIONAL)

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

Hello your name here [Log out](#)

Registration: Create account - **Personal data** - Complete

Registration: Personal data

Name ? cristiano cairo

Device name ? Your device name

Device ID ? 123456789012

Endomondo user id ? Endo@test.com

Endomondo password ? *****

Date of birth ? 31 12 2013

Gender Female

Height 0 cm

Weight 70,0 kg

Back

Continue

Your personal information is used to calculate the calories consumption when training.

PRESS CONTINUE

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

Registration: Create account - Personal data - Complete

Hello your name here [Log out](#)

Registration: Personal data

Name ? cristiano cairo

Device name ? Your device name

Device ID ? 123456789012

Endomondo user id ? Endo@test.com

Endomondo password ? *****

Date of birth ?

31 12 2013

Gender Female

Height 0 cm

Weight 70,0 kg

Back

Continue

THE REGISTRATION PROCESS ON THE CONFIGURATION MODULE IS NOW COMPLETE

Device settings

Personal profile

Training targets

Workouts

Workout selection

Leikr workouts

Workout editor

Maps

Account and connectivity

Hello your name here [Log out](#)

Registration: Create account - Personal data - **Complete**

Register: Complete

Dear your name here

Congratulations on your new Leikr.

We create our devices with the aim of empowering athletes to push their own limits and we hope that you will find the experience encouraging and helpful.



Power your potential!

Sincerely

The Leikr team

⬆

SYNCORNIZE YOUR LEIKR WATCH FOR THE FIRST TIME



- Press the two top keys on the Leikr watch.
- A message will appear on the screen: "are you sure you are XXX?"
- Press "yes"
- Synchronization start
- Synchronization complete
- Press "ok"

YOUR LEIKR WATCH IS NOW WIRELESSLY
CONNECTED TO YOUR LEIKR AND
ENDOMONDO ON-LINE ACCOUNTS

